

■ Flash functions available with cameras when used with an external Speedlight

D5600, D5500

			Speedlight compatible with CLS										Speedlight incompatible with CLS							
			SB-5000	SB-900 SB-910	SB-800	SB-700	SB-600	SB-500	SU-800		SB-R200	SB-400	SB-300	SB-80DX SB-28DX	SB-50DX	SB-28 SB-26 SB-25 SB-24	SB-30, SB-27 SB-22S, SB-22 SB-20, SB-16B SB-15	SB-23 SB-29 SB-21B SB-29S	SB-12 SB-21A + AS-6	SB-16A SB-17 + AS-6
									Commander	Close up										
Single flash	i-TTL	i-TTL balanced fill-flash *1	○	○	○	○	○	○	-	-	-	○	○	—	—	—	—	—	—	—
		Standard i-TTL	○*2	○*2	○*2	○	○*2	○	-	-	-	○	○	—	—	—	—	—	—	
	TTL	TTL flash control for Speedlights incompatible with CLS	-	-	-	-	-	-	-	-	-	-	-	-	-	—	—	—	—	—
		AA	Auto aperture flash	○*3	○*3	○*3	-	-	-	-	-	-	-	—	—	—	—	—	—	—
		A	Non-TTL auto flash	○*3	○*3	○*3	-	-	-	-	-	-	-	○	—	○	○	—	—	○
	GN	Distance-priority manual flash	○	○	○	○	-	-	-	-	-	-	—	—	—	—	—	—	—	
	M	Manual flash	○	○	○	○	○	○*4	-	-	-	○*4	○*4	○	○	○	○	○	○	○
RPT	Repeating flash	○	○	○	-	-	-	-	-	-	-	-	○	—	○	—	—	—	—	
Optical AWL	Master	Setting	Commander function	○	○	○	○	-	○*4	○	○	-	-	-	-	-	-	-	-	-
			Controllable group	A/B/C	A/B/C	A/B/C	A/B	-	A/B	A/B/C	A/B/(C)	-	-	-	-	-	-	-	-	
			Mode setting	A/B/C	A/B/C	A/B/C	A/B	-	A/B	A/B/C	A/B/(C)	-	-	-	-	-	-	-	-	
			Mode setting for remote	Individual	Individual	Individual	Common	-	Individual	Individual	A/B: Common C: M fix	-	-	-	-	-	-	-	-	
		i-TTL	Same as master	Same as master	Same as master	Same as master	-	Master+AA	Same as SB-800	Same as SB-700	-	-	-	-	-	-	-	-		
		[A:B]	i-TTL flash control	○	○	○	○	-	○*4	-	-	○	-	-	-	-	-	-	-	
	Remote	Setting	AA	Auto aperture flash	○*5	○*5	○*5	-	-	○*4	-	-	-	-	-	-	-	-	-	
			A	Non-TTL auto flash	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	
			M	Manual flash	○	○	○	○	-	○*4	-	-	-	-	-	-	-	-	-	
			RPT	Repeating flash	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	
		i-TTL	i-TTL flash control	○	○	○	○	○	○	-	-	○	-	-	-	-	-	-		
		[A:B]	Quick wireless control	○	○	○	○	○	○	-	-	○	-	-	-	-	-	-	-	
	SU-4	Master	AA	Auto aperture flash	○*5	○*5	○*5	-	-	-	-	-	-	-	-	-	-	-	-	
			A	Non-TTL auto flash	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	
			GN	Distance-priority manual flash	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	
M	Manual		○	○	○	-	-	-	-	-	-	-	-	-	-	-	-			
Remote	AUTO	Auto	○	○	○	○	-	-	-	-	-	-	-	-	-	-	-			
	M	Manual	○	○	○	○	-	-	-	-	-	-	-	-	-	-	-			

*1 Not available with spot metering.

*2 Can be also selected with flash unit.

*3 AA/Mode A selection preformed on flash unit using custom settings. Mode A will be selected when a non-CPU lens is used.

*4 Can only be selected using camera Flash Control option.

*5 Auto aperture flash mode and non-TTL auto flash mode cannot be selected in the flash unit's custom menu.

Non-TTL auto flash mode will be applied when a non-CPU lens is used.

*6 Available only in i-TTL, AA, A, GN and M mode.

*7 Available only in i-TTL, AA and A.

Cannot be configured	—	Not supported by camera
	Text entered	Not supported by camera, but flash functions are ind
Can be configured	—	Function not available with flash unit
	○	Available
	Text entered	Available; additional information noted