

■ Flash functions available with cameras when used with an external Speedlight

D7500												Speedlight compatible with CLS												Speedlight incompatible with CLS																							
												SU-800			SB-R200			SB-400			SB-300			SB-50DX			SB-80DX SB-28DX			SB-28			SB-22S, SB-22			SB-30, SB- 27			SB-23			SB-12 + AS-6			SB-16A + AS-6		
												Commander	Close up																																		
Single flash	Optical AWL	i-TTL	i-TTL balanced fill-flash *1	○	○	○	○	○	○	-	-	-	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-													
		Standard i-TTL	○*2	○*2	○*2	○	○*2	○	-	-	-	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-												
		TTL flash control for Speedlights incompatible with CLS	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-											
		AA	Auto aperture flash	○*5	○*3	○*3	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-											
		A	Non-TTL auto flash	○*5	○*3	○*3	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-											
		GN	Distance-priority manual flash	○	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-											
		M	Manual flash	○	○	○	○	○	○	○*4	-	-	-	-	-	-	-	○*4	○*4	-	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○												
		RPT	Repeating flash	○	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-										
		Commander function	○	○	○	○	-	○*4	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-										
		Controllable group	A/B/C	A/B/C	A/B/C	A/B/C	A/B	-	A/B	A/B/C	A/B/C	A/B/C	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-										
Radio-controlled AWL	Remote	Setting	A/B/C Individual	A/B/C Individual	A/B/C Individual	A/B/C Individual	A/B	-	A/B	A/B/C Individual	A/B/C Individual	A/B/C Common	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-										
		Mode setting	Same as master	Same as master	Same as master	Same as master	-	Master+A	Master+A	Same as SB-800	Same as SB-800	Same as SB-700	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-										
		Mode setting for remote	Same as master	Same as master	Same as master	Same as master	-	Master+A	Master+A	Same as SB-800	Same as SB-800	Same as SB-700	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-										
		i-TTL	i-TTL flash control	○	○	○	○	-	○*4	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-									
		[A:B]	Quick wireless control	○	-	○	○	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-								
		AA	Auto aperture flash	○*5	○*5	○*5	-	-	○*4	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-								
		A	Non-TTL auto flash	-	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-								
		M	Manual flash	○	○	○	○	-	○*4	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-								
		RPT	Repeating flash	○	○	○	○	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-								
		i-TTL	i-TTL flash control	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-					
SU-4	Master	[A:B]	Quick wireless control	○	○	○	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-						
		AA	Auto aperture flash	○*5	○*5	○*5	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-						
		AA	Non-TTL auto flash	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-					
		GN	Distance-priority manual flash	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-						
		M	Manual	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-					
		AUTO	Auto	○	○	○	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-					
		M	Manual	○	○	○	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-				
		AA	Auto aperture flash	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-			
		A	Non-TTL auto flash	○	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
		GN	Distance-priority manual flash	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
		M	Manual	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		

\*1 Not available with spot metering.

\*2 Can be also selected with flash unit.

\*3 AA/Mode A selection preformed on flash unit using custom settings. Mode A will be selected when a non-CPU lens is used.

\*4 Can only be selected using camera Flash Control option.

\*5 Auto aperture flash mode and non-TTL auto flash mode cannot be selected in the flash unit's custom menu.

Non-TTL auto flash mode will be applied when a non-CPU lens is used.

\*6 Available only in i-TTL, AA, A, GN and M mode.

\*7 Available only in i-TTL, AA and A.

Cannot be configured	—	Not supported by camera
Text entered	—	Function not available with flash unit
Can be configured	○	Available
Text entered	—	Available; additional information noted