

■ Flash functions available with cameras when used with an external Speedlight

Z 7II, Z 7, Z 6II, Z 6, Z 5, Z 9, Z 8, Z6III

Speedlight compatible with CLS															Speedlight incompatible with CLS								
	SB-5000	SB-900 SB-910	SB-800	SB-700	SB-600	SB-500	SU-800		SB-R200	SB-400	SB-300	SB-80DX SB-28DX	SB-50DX	SB-28	SB-26 SB-25 SB-24	SB-30, SB- 27 SB-28, SB- 22 SB-20, SB- 16B SB-15	SB-23	SB-29 SB-21B SB-29S	SB-12 SB-21A + AS-6	SB-16A SB-17 + AS-6			
							Commander	Close up															
Single flash	i-TTL	i-TTL balanced fill-flash *1	○	○	○	○	-	-	-	○	○	-	-	-	-	-	-	-	-	-	-	-	
	Standard i-TTL	○*2	○*2	○*2	○	○*2	○	-	-	○	○	-	-	-	-	-	-	-	-	-	-	-	
	TTL flash control for Speedlights incompatible with CLS	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
	AA	Auto aperture flash	○*5	○*3	○*3	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
	A	Non-TTL auto flash	○*5	○*3	○*3	-	-	-	-	-	-	-	-	-	○	○	-	-	○	-	-	-	
	GN	Distance-priority manual flash	○	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
	M	Manual flash	○	○	○	○	○	○*4	-	-	-	○*4	○*4	○	○	○	○	○	○	○	○	○	
	RPT	Repeating flash	○	○	○	-	-	-	-	-	-	-	-	○	-	○	-	-	-	-	-	-	
	Commander function	○	○	○	○	-	-	○*4	○	○	-	-	-	-	-	-	-	-	-	-	-	-	
	Controllable group	A/B/C	A/B/C	A/B/C	A/B	-	A/B	A/B/C	A/B/C	A/B/C	A/B/C	A/B/C	A/B/C	A/B/C	A/B/C	A/B/C	A/B/C	A/B/C	A/B/C	A/B/C	A/B/C	A/B/C	
Optical AWL	Setting	Mode setting	A/B/C	A/B/C	A/B/C	A/B	-	A/B	A/B/C	A/B/C	A/B/C	A/B/C	A/B/C	A/B/C	A/B/C	A/B/C	A/B/C	A/B/C	A/B/C	A/B/C	A/B/C	A/B/C	
	Master	Mode setting for remote	Individual	Individual	Individual	Common	-	A/B	Individual	Common	Individual	Common	Individual	Common	Individual	Common	Individual	Common	Individual	Common	Individual	Common	Individual
	i-TTL	i-TTL flash control	○	○	○	○	-	○*4	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
	[A:B]	Quick wireless control	○	-	-	○	-	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	
	AA	Auto aperture flash	○*5	○*5	○*5	-	-	○*4	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
	A	Non-TTL auto flash	-	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
	M	Manual flash	○	○	○	○	-	○*4	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
	RPT	Repeating flash	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
	Setting	i-TTL flash control	○	○	○	○	-	○	○	-	-	○	-	-	-	-	-	-	-	-	-	-	
	Remote	Quick wireless control	○	○	○	○	-	○	○	-	-	○	-	-	-	-	-	-	-	-	-	-	
Radio-control led AWL	Setting	AA	Auto aperture flash	○*5	○*5	○*5	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	Master	A	Non-TTL auto flash	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	Remote	M	Manual flash	○	○	○	○	-	○	○	-	-	○	-	-	-	-	-	-	-	-	-	-
	Setting	RPT	Repeating flash	○	○	○	○	-	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-
	Color Information Communication (flash)	○	○	○	○	○	○	○	-	-	-	-	○	○	-	-	-	-	-	-	-	-	-
	Color Information Communication (LED light)	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	Auto FP high-speed sync *6	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	FV lock *7	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	AF-assist for multi-area AF	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	Modeling illumination using camera control	○	○	○	○	○	○	○	Signal only	-	Remote only	-	-	-	-	-	-	-	-	-	-	-	-
SU-4	Modeling illumination using flash control	○	○	○	○	-	-	-	Signal only	-	Remote only	-	-	-	-	-	-	-	-	-	-	-	-
	Red-eye reduction	○	○	○	○	○	○	-	○	-	-	-	-	-	○	○	-	-	-	-	-	-	-
	Unified flash control	○	-	-	-	-	-	-	○	-	-	-	-	-	○	○	-	-	-	-	-	-	-
	Flash mode setting from camera	○	-	-	-	-	-	-	○	-	-	-	-	-	○	○	-	-	-	-	-	-	-
	Scenes/special effects flash control	○	-	-	-	-	-	-	○	-	-	-	-	-	○	○	-	-	-	-	-	-	-
	Test firing from camera	○	-	-	-	-	-	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	Flash unit firmware update via camera	○	○	-	○	-	○	-	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	Master	AA	Auto aperture flash	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	Master	A	Non-TTL auto flash	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	Master	GN	Distance-priority manual flash	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	Master	M	Manual	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	Remote	AUTO	Auto	○	○	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	Remote	M	Manual	○	○	○	○	○	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-

Cannot be configured	—	Not supported by camera
Text entered	—	Function not available with flash unit
Can be configured	○ Available	Text entered Available; additional information noted

\*1 Not available with spot metering.

\*2 Can be also selected with flash unit.

\*3 AA/Mode A selection preformed on flash unit using custom settings. Mode A will be selected when a non-CPU lens is used.

\*4 Can only be selected using camera Flash Control option.

\*5 Auto aperture flash mode and non-TTL auto flash mode cannot be selected in the flash unit's custom menu.

\*6 Non-TTL auto flash mode will be applied if a non-CPU lens is used without specifying the lens' maximum aperture using **Non-CPU lens data** in the camera's setup menu.

\*7 Available only in i-TTL AA, A, GN and M.

\*8 Available only in i-TTL AA and A.